

Spare part list Euroboor EBM.360		
1	360.1001	Screw
2	360.1002	Motorhousing left side
3	360.1003	Label (Left side)
4	360.1004	Motorhousing right side
5	360.1005	Label (Right side)
6	360.1006	Sensor Holder
7	360.1007	Bolt M5x60
8	360.1008	Motor Assembly
9	360.1009	Pin 6x60
10	360.1010	Lower Inner Gear Plate
11	360.1011	Gasket
12	360.1012	Bearing 608
13	360.1013	1st Gear Axle
14	360.1014	Spindle Gear
15	360.1015	Bearing 626ZZ
16	032.0191	Adaptor ring
17	360.1017	Bearing 6003DDU
18	360.1018	Gear Casing
19	360.1019	Spindle Drive Shaft
20	360.1020	Bolt M5x10
21	360.1021	Tank holder
22	360.1022	Slide
23	360.1023	Washer 6
24	360.1024	Bolt M6x20
25	360.1025	Bolt M6x14
26	360.1026	Steady
27	020.0116	Spindle
28	360.1028	Rack
29	020.0081	End Screw
30	020.0077	End Plate
31	360.1031	Brass rail (Left side)
32	360.1032	Brass rail (Right side)
33	360.1033	Motor cable protection screw
34	360.1034	Pressing strip
35	360.1035	Wiring cover
36	360.1036	Frame
37	360.1037	Magnet
38	020.0091	Setting Screw
39	020.0096	Setting Nut
40	360.1040	Motorcable cover
41	360.1041	Wire #1
42	360.1042	Wire #2
43	360.1043	Wire #3
44	360.1044	Wire #4
45	360.1045	Connector
46	020.0041	Coupling nut
47	020.0061	Capstan hub
48	020.0066	Arm
49	360.0001	Battery Pack
50	360.1050	Bolt
51	360.1051	Screw
52	360.1052	Battery Contact board
53	360.1053	Connector
54	360.1054	Connector
55	360.1055	Battery slide base
56	360.1056	On Switch
57	360.1057	Off Switch
58	360.1058	Magneet Switch
59	360.1059	Wiring + connector
60	360.1060	Wiring + connector
61	PP.360EU	Front Panel Plate
62	020.0101	Crimp nut
63	360.1063	Screw M3x8
64	360.1064	Control Unit
65	PP.R360EU	Rear Panel Plate



